




Prepared for and presented at Chemnitzer Seminar "System Integration Technologies", June 23-24, 2015

Oxide Free Direct Wafer Bonding

Anneliese Pönninger




Outline

- Introduction
- Direct Wafer Bonding
- Oxide-free Direct Wafer Bonding
 - ComBond[®] Technology
- EVG[®]580 ComBond[®] Equipment
- Applications

EVG – At a glance



- Founded in 1980 by DI Erich and Aya Maria Thallner as an engineering partner for the semiconductor industry.
- Headquartered in Austria, with fully owned subsidiaries in the USA, Japan, South Korea, China and Taiwan; worldwide network of representatives.
- More than 700 employees globally, approx. 600 at EVG headquarters in Austria.
- Recognized technology and market leader in wafer processing solutions for semiconductor, MEMS and nanotechnology applications.
- Installed base in excess of 2,000 tools in high volume production as well as university and industrial R&D institutions worldwide.
- EVG continues to invest a large double digit percentage of its revenue in application-oriented research and development.




Markets and Typical End Products

**Advanced Packaging
3D Interconnect**





CMOS Image Sensors

**Compound Semiconductor
Silicon-Based Power Devices**






LEDs

MEMS
(Micro Electro Mechanical Systems)






Motion sensors

Nanotechnology

DNA chips / micro labs

**SOI (Silicon On Insulator)
Engineered Substrates**





Micro processor wafers



Direct Wafer Bonding

Wafer Bonding: Overview






Direct Wafer Bonding Characteristics


- Initial spontaneous bonding occurs when surfaces are brought into physical contact.
- Covalent bonds between surfaces formed during application of heat.
- The resulting bond strength is as high as the bulk fracture strength.
- The resulting bond is permanent.

Classical and Plasma Activated Fusion Bond


1 Van-der-Waals bonds





2 Water diffusion



3 Formation of covalent bonds



4 Closure of nano-gaps



- Classical:
SiO₂ viscosity due to high temperature annealing
- Plasma activated:
Enhanced diffusion at low temperatures

Plasma Activated Wafer Bonding


- Requires **thick oxide** in the interface

Thick oxide →


Electrical resistance →

Conductive interfaces not possible


- RT covalent bonding **possible**, but industrially **not practical**



Room temperature process not viable



EVG®810LT LowTemp™ Plasma Activation System



Gemini® FB Automated Production Fusion Bonding System



See: T. Plach, K. Hingerl, S. Tollabimazraehno, G. Hesser, V. Dragoi and M. Wimplinger, *J. Appl. Phys.*, **113**, 094905 (2013).



Oxide-free Direct Wafer Bonding


ComBond[®] Technology




Motivation for ComBond®




- Motivation
 - Covalent bonding technology
 - Oxide-free, conductive interface
 - Room temperature or low temperature process
 - Applications
 - Heterogeneous integration
 - Layer transfer for advanced substrates
 - Improved metal/metal bonding
 - High vacuum encapsulation (MEMS)



Particle-free and void free bonding



Si/Si bond interface – minimum amorphous layer



GaAs/InP bond interface – minimum amorphous layer

- Requirements
 - Surface activation (oxide removal, avoid roughness increase)
 - High vacuum (retain oxide-free surface)
 - Low (room) temperature bonding process (retain crystal structures, minimize amorphous layer growth, avoid stresses due to CTE mismatch)
- Solutions
 - **ComBond®**: Gentle surface sputtering using energized projectiles of an inert gas effectively removes oxides and other molecular contaminations. Re-oxidation is prevented by processing in high or ultra high vacuum.


ComBond® Process

▪ Why does ComBond® require high vacuum?

→ If an oxide-free interface is required, it is not enough to remove the oxide. Re-deposition of oxide needs to be prevented, as well.

Base Pressure [mbar]	Vacuum Classification	Comment	Time to form 1 monolayer [s]
1000	Rough Vacuum	Atmosphere	4.10E-08
100	Rough Vacuum		4.10E-07
10	Rough Vacuum		4.10E-06
1	Rough Vacuum		4.10E-05
0.1	Rough Vacuum	EVG®810LT process pressure level	4.10E-04
0.01	Rough Vacuum		0.004
0.001	Rough / Medium Vacuum	EVG®810LT base pressure level	0.041
1.00E-04	Medium Vacuum		0.41
1.00E-05	Medium Vacuum	EVG®580 ComBond® process pressure level	4.10
1.00E-06	Medium / High Vacuum		41.05
1.00E-07	High Vacuum		410.45
1.00E-08	High Vacuum	EVG®580 ComBond® base pressure level	4104.54
1.00E-09	High / Ultra High Vacuum		4.10E+04
1.00E-10	Ultra High Vacuum		4.10E+05

Immediate reoxidation



Enough time left to contact wafers before reoxidation occurs.

Assumptions:

- Each H₂O molecule from background contamination that hits the Si surface will stick.
- H₂O partial pressure is 10 % of base pressure.

ComBond® Achievements




- High vacuum process ($<10^{-8}$ mbar)
- Surface activation and oxide-removal
- Room (low) temperature bonding
 - Oxide-free interface
 - Minimum thickness of amorphous layers
 - Minimum crystal dislocations


ComBond® Process Results




- Surface activation
 - Dry etching with energized particles
 - Uniform oxide removal
 - Low surface roughness increase



Silicon: Roughness $RMS(R_q) < 0.1\text{nm}$



GaAs: Roughness $RMS(R_q) < 0.1\text{nm}$




InP: Roughness $RMS(R_q) < 0.6\text{nm}$


ComBond[®] Process Results

- Si-Si Bond
HR-TEM image reveals an amorphous layer of <1 nm thickness in the bond interface.

Oxide-free!




Oxygen signal



Si/Si: amorphous layer thickness <1nm

ComBond® Process Results




ComBond[®] Process Results




C-SAM scan

Example 1



Si/Si

Example 2







Si/Si

Bond strength > 2.5 J/m² (all measurement positions broken)



ComBond® Process Results

GaAs / InP wafer bonding



Oxide-free Interface!



Equipment Solutions

EVG580[®] ComBond[®]




EVG[®]580 ComBond[®] Equipment



- Requirements
 - Surface activation (oxide removal, avoid roughness increase)
 - High vacuum (retain oxide-free surface)
 - Low (room) temperature bonding process (retain crystal structures, minimize amorphous layer growth, avoid stresses due to CTE mismatch)
- Solutions


High Vacuum System



CAM (ComBond Activation Module)




Bond Module



EVG[®]580 ComBond[®] Equipment



- Fully automated high vacuum system
- Modular design
- Flexible configuration
- Cassettes or EFEM
- Wafers up to 200 mm
- Throughput: 20 units / hour




BASIC FUNCTIONS
Vacuum bake
Optical pre-aligner
Robot unit with end-effector(s) and controllers
Vacuum system with gauge, turbomolecular and roughing pump
View ports
Wafer flipping

VACUUM CAPABILITY	Pressure [mbar]
Handling system	< 7*10 ⁻⁸
Cassette load lock	<1*10 ⁻⁶
CAM module	< 9*10 ⁻⁸
Bond module	< 9*10 ⁻⁸

CONFIGURATIONS	3 Process Modules	5 Process Modules	6 Process Modules
Wafer size	up to 200 mm	up to 200 mm	up to 200 mm
Load lock	1 cassette station or 1 manual load port	2 cassette stations or EFEM with up to 4 cassettes	2 cassette stations or EFEM with up to 4cassettes
CAM module	1	2	2
Bond chamber	1	1	1
Free ports		1	2
Robot	Single arm	Dual arm	Dual arm

EVG®580 High Vacuum Cluster



- Operated at base pressures $< 7 \times 10^{-8}$ mbar
- Maintains the fully automated wafer transport and handling
- Maximum six process modules
- Maximum wafer stack height 4 mm
- Buffer station for up to two wafers
- Single or dual arm robot
- Integrated bake out
- Optical prealigner
- Automatic wafer centering sensor
- Optical sensor for wafer detection
- Load lock
 - Manual, cassette, EFEM loading
 - Double pitch cassette for up to twelve wafer
 - Pressure recovery 3 minutes to $\leq 6 \times 10^{-5}$ mbar
 - High speed vent (vacuum to atm) ~ 1 min



High Vacuum Handling System Transport Chamber




- Bake out of chamber wall
- Base pressure (with bake < 24h)
 - < 1×10^{-7} mbar Turbo pump
 - < 7×10^{-8} mbar Cryo pump (optional)



EVG[®] 580 ComBond[®] Activation Module (CAM)

- ComBond[®] Activation Module (CAM)
Surface modification treatment to allow covalent bonding at or near room temperature.
- The CAM surface treatment technology achieves
 - Oxide-free and particle-free surfaces
 - Low surface roughness
 - Uniform oxide removal and surface activation
 - High throughput
- Process chamber pressure
 - Base pressure <math>< 9 \times 10^{-8}</math> mbar
 - Process pressure $\sim 1 \times 10^{-5}$ mbar




CAM Specifications	
Roughness increase	< 0.1 nm
Cleanliness	<math>< 1 \times 10^{10}</math> metal ions / cm ² < 5 particles (> 0.2 μm) added per wafer
Oxide removal (Si)	up to 15 nm / min

EVG[®] 580 Bond Module



- Electrostatic chucks
- Heated and not heated version
- Enhanced vacuum level of $< 9 \times 10^{-8}$ mbar
- Open space between heaters of 25 mm for enhanced outgassing
- Active water cooling of top and bottom heaters



EVG 580 Bond Module	Technical Data
Piston force	Up to 100 kN
Maximum temperature	400 °C
Heating rate	45 °C / min
Wafer stack height	< 4 mm
Purge gas lines	1

EVG[®]580 ComBond[®] Configurations



	1	2	3	4	5
Configuration					
Process Modules	3	5	5	6	6
Cassette Station	1 (12 slot cassette) optional single substrate loading (up to 2 substrates)	2 (12 slot cassette)	up to 4 (25 slot cassette)	2 (12 slot cassette)	up to 4 (25 slot cassette)
*Estimated Throughput [Wafer/h]	~ 8	~ 13	~ 15	~ 16	~ 20

*calculated with current BKM Recipe and max. amount of process modules






Applications

Heterogenous integration, layer transfer, MEMS,..

Applications - Examples


- Multi-junction solar cells based on III-V semiconductors



- Bond forms cell 2

- Bonding of solar cell stacks to bottom cells
- Bonding of III-V layers to form a cell structure with certain wavelength sensitivity
- Any combination possible (CS on CS or Si, Ge,..)
- Certain buffer layers not required
- Room temperature bonding process
- Electrically conductive bond interface

- Power Devices




Crystalline SiC on polycrystalline SiC*

- Vertical Power Devices need conducting interface
- Oxides can act as trap states increasing resistance and reducing device performance
- Engineered substrates as growth templates can save costs

*ComBond Result, Courtesy of GT Advanced Technology

- **Improved Vacuum Encapsulation**
- Wafers are baked out prior to aligning and clamping.

- Will be open faced



- Much larger spacing than when clamped
 - Typical clamp thickness is 100-200 μ m
 - Stacked bakeout module will can have spacing of 10-20mm
- This increased spacing improves the desorption of water molecules from the surface of the wafer by increasing the probability that the desorbed water molecule will 'escape'



Summary

- Surface activation is needed to achieve superior bonding quality at low temperatures through formation of covalent bonds
- Advanced applications need advanced surface activation methods to
 - Encapsulate high vacuum (MEMS)
 - Remove surface oxides
 - Eliminate the need for thermal annealing
- EVG[®]580 ComBond[®] represents a solution to such advanced application demands
- **Proven facts:** EVG[®]580 ComBond[®] and its CAM are capable to
 - Maintain **high vacuum levels** at $\sim 10^{-8}$ mbar
 - Perform with **highest cleanliness**
 - Effectively **remove surface oxides** on various wafer materials
 - Retain or **even improve** surface roughness after activation
 - Produce **real room temperature** Si-Si wafer bonds with **maximum bond strength**



Thank you!

Data, design and specifications may not simultaneously apply; or depend on individual equipment configuration, process conditions and materials and may vary accordingly. EVG reserves the right to change data, design and specifications without prior notice. All trademarks, logos, website addresses or equipment names that contain the letters or words "EVG" or "EV Group" or any combination thereof, as well as the following names and acronyms are registered trademarks and/or the property of EV Group: ComBond®, CoverSpin™, EZB®, EZ Bond®, EZD®, EZ Debond®, EZR®, EZ Release®, GEMINI®, HERCULES®, HyperIntegration®, IQ Aligner®, LowTemp™, NanoAlign®, NanoFill™, NanoSpray™, NIL-COM®, NILPhotonics™, OmniSpray®, SmartEdge®, SmartView®, The Triple "i" Company Invent-Innovate-Implement®, Triple i®. Other product and company names may be registered trademarks of their respective owners.



EV Group Confidential and Proprietary

www.EVGroup.com